

Color Chart  
Basic Needle Case

Graphic: needle chart

Graphic: color chart

Stitch Count: 1640  
Color Changes: 0  
Size: 120 x 76.6mm  
4<sup>3</sup>/<sub>4</sub>" x 3"

**NOTE:** Thread machine with the same color chosen for the final decorative stitch. There is no need to change out thread colors. The different colors serve to stop the machine. Different thread colors also help explain the function of each stop.

Color #1: Stitch directly on the hooped Sulky® Soft 'n Sheer™ Stabilizer  
Color #2: Secures cork fabric to stabilizer

**NOTE:** If adding a design to the needle case cover, do so at this point

Color #3: Before stitching, remove hoop from machine but leave project secured in frame

Add felt fabric to the back-side of the stabilizer and return hoop to the machine. The felt fabric will be underneath the hoop

Stitch color stop #3 to secure felt to cork fabric

Color #4: Stitches a straight line on vertical center of the needle case

Color #5: Stitches a decorative border around the entire needle case, finishing outer edges

Once completed, remove the project from the hoop. Using a straight edge and a rotary cutter, trim close to the outer edge of the decorative stitching. Cut about 1/16" to the outside of stitching. Cut through all layers being careful to not cut into any stitches.

Graphic: cutting line

Fold case in half. Place the folded needle case under a heavy weight, such as a stack of books to decisively crease.